

GENZ·BENZ

GB 412 G-FLEX GUITAR ENCLOSURE

MONO OPERATION -

- Mono 8 ohm Jack: Use this jack for mono 8 ohm operation.
- Mono Extension Jack: Use this jack to connect another extension cabinet when using the mono input jack (daisy chaining).

STEREO OPERATION -

Note: Two amplifier sections or channels are required for stereo operation.

- Left 4 ohm Jack: Use this jack to connect one amplifier section or channel to the left 4 ohm speakers.
- Right 4 ohm Jack: Use this jack to connect a second amplifier section or channel to the right 4 ohm speakers.

